



Quick Start

BeamWatch® PLUS

Equipment



BeamWatch PLUS



Glass Inserts



Gigabit to USB 3.0 Adapter



Polyurethane tubing



Power Supply Adapter Kit



Ethernet Cable 4.5m



Power Supply Cable


Setup

3.

Connect purge gas source (Air, Nitrogen, Argon 10 SLPM (35 PSI / 2.5 BAR).


5.

Set up a suitable beam dump. An Ophir Power Sensor is recommended.




4.

Attach power supply cable with proper adapter



2.

Attach the BeamWatch to PC Computer (Use Gigabit to USB 3.0 Adapter as needed).



1.

Secure BeamWatch unit to a flat surface.

7.

Install the correct glass insert for the wavelength of the laser.

8.

Install BeamWatch software on the PC.

9.

Launch the software. Begin collecting data in real time!


6.

Center the beam in the BeamWatch Aperture.
• Align the beam to the scribe marks on the alignment tool.
• The scribe line on the side of the unit is the nominal center location of the camera.




Operating Limits


BW-PLUS-45, Wavelength = 1070nm



Wavelength = 1070nm



BW-PLUS-45, Wavelength = 515nm



Wavelength = 515nm

