Field Upgrade of the firmware is a very simple process

1. After downloading the Field Upgrade Tool and copying it to your local drive, double-click on the file to run.

2. The Field Upgrade Tool expects .NET Framework 4 to be installed on the computer.

3. If not already installed, download .NET Framework 4 from Microsoft's web site at http://www.microsoft.com/en-us/download/details.aspx?id=17851

4. While the Field Upgrade Tool is self-extracting itself, the following will be displayed on the screen

5. Follow the on-screen instructions to set up the StarLite/StarBright for the firmware version upgrade.

StarLite Field Upgrade Tool Version:1.18

The StarLite device has been detected

Release all keys and press "Next" to start field upgrade process.

[Next >]   [Cancel]

StarLite Field Upgrade Tool Version:1.18

Firmware upgrade in progress

Stage 1   Completed.
Stage 2   in progress ...

[Next >]

StarLite Field Upgrade Tool Version:1.18

StarLite has been successfully upgraded.

Stage 1   Completed.
Stage 2   Completed.
Stage 3   Completed.

Power off the StarLite.
Press the On/Off button again.
StarLite will be running with the new version installed.

[Exit]